



CS2500



CS2500



CS2500

Ref	Description	Part number
4	Spring	TT00409
5	Spring box	TT00505
7	Reel	TT00707
14	Oil cap	TT01403
15	Seal oil cap	TT01502
17	Palm oil Cap	TT01703
21	Flywheel	TT02112
25	Bolt STx14	TT02501
27	oil seal 12x22x5	TT02702
40	Piston Ring	TT04012
42	Snap Ring, Piston Pin	TT04205
43	Piston Pin	TT04312
44	Piston	TT04412
45	elastic ring needle bearing	TT04506
46	Needle bearing	TT04612
47	Key 3x10	TT04701
48	Crankshaft	TT04812
55	vent	TT05502
61	oil filter	TT06103
62	Chain catcher	TT06202
63	oil tube	TT06303
65	Plate injector	TT06504
67	oil pump	TT06704
70	plate oil pump	TT07004
71	worm	TT07102
72	needle bearing	TT07204
74	Drum	TT07404
75	Spacer clutch	TT07503
76	Clutch	TT07607
79	Wooden teeth	TT07903
80	Plate braker spring	TT08004
83	Braker lever	TT08304
85	Brake band connectin rod	TT08503
86	Brake band	TT08604
87	Positioning pin	TT08702
91	main spring braker	TT09102
92	Tension cover	TT09204
93	Adjusting screw pin	TT09304
95	adjusting screw gear	TT09502
97	Braker cover	TT09704
107	Fuel tank & body	TT10711
108	Trigger control arm	TT10805
109	rear handle cover	TT10904

Ref	Description	Part number
110	Fuel Filter	TT11001
111	Balancer	TT11101
112	Balancer seat	TT11201
113	Rod	TT11303
115	Throttle trigger	TT11506
116	Torsion spring trigger	TT11603
117	pin 5x30	TT11702
119	Cap fuel filter	TT11909
120	Handle	TT12005
125	Bubble	TT12501
126	Knob	TT12603
128	Cover Filter	TT12809
129	air filter pressure plate	TT12902
130	element	TT13010
131	on/off switch	TT13101
133	muffler cover	TT13307
135	muffler	TT13509
136	gasket muffler	TT13602
137	bolt M5x445	TT13702
139	coil	TT13912
140	spark plug L7T	TT14002
141	cylinder	TT14112
143	gasket inlet pipe	TT14309
144	inlet pipe	TT14410
146	air filter seat	TT14603
147	damper rod	TT14704
149	Choke rod	TT14905
150	Insulation gasket	TT15002
152	Retaining Ring	TT15202
153	carb	TT15312
159	Guide bar 12"	TT15906
160	chain 12"	TT16006
161	cover guid bar 12"	TT16106
165	fuel pipe	TT16505
167	starter assy	TT16709
198	bearing 6001	TT19801
200	Cylinder bolt M5x20	TT20002
231	Locknut seal	TT23102
235	Dustproof cover	TT23502
237	Damper	TT23702
238	dustproof cover	TT23803
241	Braker assy	TT24103
242	Sub Lever	TT24201
243	pin 3x10	TT24302
244	spring front guard	TT24401
245	spring seat	TT24501



Ref	Description	Part number
247	Torsion spring braker	TT24702
248	front guard	TT24805
249	torsion spring hammer	TT24902
250	hammer	TT25001
251	Casing hammer	TT25101
252	Casing front guard	TT25202
262	intake seat	TT26202
263	oil seal 12x28x6	TT26302
264	Oil outer pipe	TT26402
265	oil inter pipe	TT26502
275	spacer	TT27502
277	Outlet oil pipe	TT27702
278	nozzle joint	TT27802
280	fuel tank cover	TT28002
284	damping seat	TT28402
501	Cylinder cover	TT50101
502	washer	TT50201
503	cord	TT50301
504	fuel pipe	TT50401
505	stater washer	TT50501
506	Handle pad	TT50601
507	washer	TT50701
508	washer 5x10	TT50801
509	bolt st4.8s16F	TT50901
511	block chain screws	TT51101
512	rear handle	TT51201
513	hanger	TT51301