


HYUNDAI

POWER PRODUCTS

HHT26P



HYUNDAI

POWER PRODUCTS

HHT26P

Ref	Description	Part number
7	start plate	HY00704
11	clutch gasket	HY01102
12	cltuch screw	HY01201
16	gasket	HY01601
17	spacer	HY01701
18	side cover	HY01801
21	flywheel	HY02108
26	spring	HY02602
27	12*22*7 oil seal	HY02701
39	cylinder gasket	HY03901
40	piston ring	HY04010
44	piston	HY04407
46	needle bearing	HY04608
47	woodruff key	HY04701
48	crankshaft	HY04806
49	pin	HY04906
50	crankcase gasket	HY05004
51	crankcase	HY05104
76	clutch	HY07603
107	tank	HY10705
108	trigger control arm	HY10802
110	fuel filter	HY11001
114	oil pipe	HY11403
115	throttle trigger	HY11503
116	spring	HY11603
119	tank cap	HY11904
120	handle bar cover	HY12003
124	plastic cover	HY12404
126	knob	HY12605
128	air filter cover	HY12806
130	air filter sponge	HY13006
131	switch	HY13103
135	muffler	HY13506
137	screw	HY13703
139	ignition	HY13908
140	spark plug	L8RTF
141	cylinder	HY14104

Ref	Description	Part number
143	intake gasket	HY14301
144	intake tuve	HY14404
153	carb	HY15305
164	air fitler seat	HY16404
167	starter	HY16704
168	muffler gasket	HY16804
169	cable	HY16902
171	carb gasket	HY17105
198	6001 bearing open	HY19801
212	Cushion	HY21201
229	bearing 6001 Closed	HY22901
230	driver	HY23001
231	gearbox casing	HY23101
232	oil glibe	HY23201
238	wheel shaft	HY23801
239	anit attrition gasket	HY23901
240	gearbox gasket	HY24001
241	wool gasket	HY24101
247	casing	HY24701
248	bracket	HY24801
250	layer aluminium	HY25001
251	big gear	HY25101
252	wear rail	HY25201
275	calliper	HY27501
284	damper	HY28402
289	spring	HY28901
301	bracket	HY30104
308	handle	HY30801
315	pin	HY31501
317	gear	HY31701
318	cable	HY31801
319	down layer	HY31901
320	blade plate	HY32001
333	Convulated tubing	HY33301
334	cable	HY33401
335	spring	HY33501